



testo 770 · Clamp meter

Startup instructions



Power ON / OFF






A - Current

Auto mode



Manual mode






V - Voltage

Auto mode



Manual mode







Ω / \bullet) / \rightarrow / \dashv

Auto mode
(testo 770-3)



Manual mode
testo 770-1/-2




SELECT — 2 s → Auto mode

μA (testo 770-2/-3)

Auto mode




Manual mode



W, PF, VA, VAr (testo 770-3)

W AC




SELECT

Inrush



A AC
— 1 x →




— 2 s → Auto mode

Min/Max/AVG



Max
— 1 x →



Min
— 2 x →



AVG
— 3 x →



— 2 s → Auto mode

°C / °F (0590 0021)



ZERO °C / °F
— 2 s →
°C/°F




ZERO — 2 s → Auto mode
°C/°F

APO off



Press
and
hold
SELECT + Power
ON →



Bluetooth and testo Smart Probes App (testo 770-3)



Press
and
hold



+

Power
ON



Free download
testo Smart Probes App



Requires iOS 8.3 / Android 4.3 or later,
plus mobile end device with Bluetooth® 4.0

